

**DART**RELEASED  
10/7/92

PPP

Part Number D350-600-146

Description Spacepod  
Door Assembly RH

Box Part Number MBX104 Dimension 44" x 33.5" x 6"

Other Packaging MF1612 MF4631E / MF4631F  
(1) sheet of styrofoam

Logo Decals D3567-2

**Packaging Instructions and Decal Placement****D350-600-146**

Apply Dart tape to cover box. Put a piece of styrofoam at the bottom of the box and (2) pieces of MF1612 at each corner of the box. Put in the door face down, wrap kit in foam, identify and add to the box in front of the door. Put a piece of MF4631E at one corner of box so the door does not move. Put 1 1/2 piece of MF4631F on top of door. Close box. Strap (3) times and staple. Apply clear tape to straps. Apply D2729-3 label as per instructions in QSI 014 section 4.5

D2729-1

D2729-3

<b>DART</b> Dart Aerospace Ltd. 1270 ABERDEEN ST HAWKESBURY ON CANADA K6A 1K7		TC APPROVAL # 09-09 TEL: 1-613-632-5200	
P/N	D350-600-146	CHG	CHG003
DESC	Spacepod Door Assy RH	SIC	SH93-88
LOT	BXXXXX	SIC	SR00098NY
DATE	AS350/355	SIC	SR00099NY
MADE IN CANADA			

Revision: **FD**Date: **07-09-24 09.09.10**

H:\Admin-qat\iso\forms\PPP-1.Rev.A

**DART****Dart Aerospace Ltd.**1270 Aberdeen Street  
Hawkesbury, ON K6A 1K7  
CANADA  
TEL.: 1 613 632-5200**SPACEPOD DOOR ASSY RH****P/N: D350-600-146 CHG003****B/N: BXXXXX**